2D Barcode Scanner

Quick Start Guide

- ▶ 2.4G Wireless +USB Wired (Wireless Version)
- ▶ Built-in FLASH memory, supports breakpoint resume
- ► Support Windows XP/7/8/10, Mac OS

Packing List:


- Barcode Scanner*1
- USB Cable*1
- Quick Start Guide*1
- Certificate of Approval*1
- Setup Card Inventory Function (Wireless Version)

V1.0

2D Barcode Scanner Overview

It integrates high-performance processor decoding board, it has fast decoding, high-precision ability, and high anti-interference ability. It can easily read barcodes on paper, goods and other material. It also boosts high scanning speed and powerful reading ability with accuracy.

Appearance:



Functions Setup:

2.4G Barcode Scanner can setup all default functions through reading the setup barcodes.



- ★ Design of whole body anti-vibration rugged
- * Extremely comfortable handle feel
- ★ 1800mAh large capacity lithium battery(Wireless Version)
- ★ Independent intellectual property rights
- ★ Button life up to 300 million times

LED Indicators

Indicator Colour

Blue LED Flashing Green LED Flashing

Two short beeps, high tone

Red LED

Meaning

Meaning

Buffer fail

Good Read, with one short beep (high tone)

Configuration correct

The red indicator will light during charging, and off when full charged

Beeper

Beeping

Four short beeps, tone ascending Power on

One short beep, high tone Read barcode

Four short beeps, tone descending Power off

Three short beeps, tone ascending Configuration correct

Two short beeps(low tone) and stop scan when press scan key, it means battery no power. (wireless version)

Common Function Barcodes



Suffix with Tab



Suffix with Enter+Tab

Enable Prefix with '123'

(Test)



Disable Prefix















Suffix with Tab+Enter



Suffix with Space



Disable Suffix



Power on Wipe Cache



Using the barcode setting tool which developed by our company, you can directly generate a 2D barcode of Prefix/Suffix, scan and setting the Prefix/Suffix required.



Enable Suffix with '987 (Test)



Power on Do not Wipe Cache





Due to the factory test of barcode scanner and adapter is separately, some scanners may not paired with the adapters. If you get the scanners can't transmit data successfully, please finish pairing with the following operations. It needs around 3–15 seconds.











DISCLAIMER

- > WE DISCLAIM ANY AND ALL LIABILITY FOR THE DAMAGES CAUSED BY NATURE DISASTER, SUCH AS EARTHQUAKE, FLOOD ETC.
- > UNDER NO CIRCUMSTANCE, CILICO DISCLAIMS ANY AND ALL LIABILITY FOR ANY DAMAGES WHICH IS CAUSED BY THE USE OF OUR PRODUCTS (INCLUDING THE DAMAGES CAUSED BY USING THE QUICK START GUIDE), SUCH AS THE COMPANY PROFIT LOSS, CREDIT LOSS, INTERRUPTION OF BUSINESS, STORAGE DATA LOSS / CHANGES OR ANY OTHER PARTICULAR, DIRECT / INDIRECT LOSS
- > WE DISCLAIM ANY AND ALL LIABILITY FOR THE DAMAGES WHICH IS CAUSED BY THE MISUSE OF COMMUNICATIONS HARDWARE OR SOFTWARE WE DON'T SPECIFIED.
- > FOR THE INFORMATION, DATA, FILES OR ANY OTHER PRODUCTS AND SERVICES WHICH ARE ACCESSED BY USING OF OUR DEVICES, WE DO NOT PROVIDE ANY FORM OF GUARANTEE OR TECHNICAL SUPPORT. AND WE DISCLAIM ANY AND ALL LIABILITY FOR THE USING OF ABOVE MENTIONED BY THE USERS
- > WE DISCLAIM ANY TYPE OF GUARANTEE AND TECHNICAL SUPPORT LIABILITY FOR THE THIRD-PARTY SOFTWARE WHICH IS USED BASED ON OUR PRODUCTS.
- > THIS MANUAL IS DELIVERED ON AN "AS-IS" AND "AS-AVAILABLE" BASIS, EXCEPT WHERE PROHIBITED BY LAW WE DO NOT MAKE ANY TYPE OF SPECIFIC PROMISES. TO THE ACCURACY OR RELIABILITY OF THE CONTENT.



Warning:

1. Please remove the power and USB cable under thunderstorm weather conditions to avoid damage from thunder and lightning. 2.Keep away from heat sources, please ensure sufficient air

circulation.

3.Pay attention that the scanner is waterproof during storage. transportation and running.
4.Please use DC5V 500mA power adapter.

More function setting, please contact us